




This Kit Contains:


- x1 Fabric Graphic Panel
- x2 Bases
- x6 Screws
- x4 Angle Plates
- x4 Single Lipped Poles 1000mm long (Male/Female Connectors)
- x2 Single Lipped Poles 1200mm long (Male/Female Connector)
- x2 Single Lipped Poles 1200mm long (Female/Female Connector)



STEP 1
Screw together both pair of 1000mm poles to make the 2metre uprights.




STEP 2
Place the angle plate on the base and then screw the 2m upright pole to the base. repeat for the other base.



Do not over tighten

STEP 3
Screw together both pair of 1200mm poles to make the 2.4 metre Cross pole.




Female End / Male End

Single Lipped Poles 1200mm long (Male/Female Connector) / x2 Single Lipped Poles 1200mm long (Female/Female Connector)

Do not over tighten


STEP 4
Screw the 2nd set of angle plates to each end of one of the assembled cross poles using the white plastic screws.



Screw the cross poles and angle plates to the top of the uprights using the white plastic screws.

STEP 5
Carefully feed the top of the fabric banner through the slot in the top cross poles. Then feed the bottom of the banner through the other cross pole

STEP 6
Screw the bottom cross pole to the angle plates to the bases using the white plastic screws.



STEP 7
Tension the Fabric banner by rotating the top and bottom cross pole.

